



EVERBASE[®] 3

INSTALLATION INSTRUCTIONS

Install Your Flooring



STEP 1.

Your baseline must be a straight line, which you can create using string or a laser guide. Place the straight edge of the first tile along this baseline. For the fastest installation, begin at the Start Point shown above and work from right to left. Make sure the top and right sides of each tile use the male connectors, while the left and bottom sides use the female connectors.

STEP 2.

Insert the male connector of the new tile into the female connector on the left side of the installed tile at a 45-degree angle. Lower the tile into place, then step down gently along the connector to ensure it locks securely.

STEP 3.

Continue installing tiles from right to left until you reach the desired row length. Once the first row is complete, begin the second row by aligning the male connectors on the top of each tile with the female connectors on the bottom of the row above. Insert the connectors at a 45-degree angle, lower each tile, and step along the connection line to lock it in place. Repeat this process for each tile in the row.

STEP 4.

Repeat Step 3, row by row, until the entire installation area is covered with flooring tiles.

Visual Installation Process

