

Floor Screen Panel

Assembly Instructions



For questions regarding your Floor Screen Panel please contact us at 1-855-457-1473 or customerservice@versare.com

1. Remove window panel and lay flat on the ground. If there is a film covering, remove before proceeding.*

2.



Attach the foot assembly by sliding it on open section of channel. Repeat for other side.

3. Lift your Floor Screen Panel up in to position.



Helpful Tips:

- * Pull film from frame edge in small sections at a time. You can also carefully cut the film, with a box cutter, along the frame and peel it from the window panel material.