




# OPERABLE WALL (Sliding)


**Note:** You will need to purchase the appropriate hardware for your wall conditions.  
Anchors not included.



Parts Included




Recommended Tools




1

Remove screws from bottom panels.

(Top Panels)




(Bottom Panels)




2

Connect top and bottom panels. Then reinsert screws.



3

Attach wall mount hinges.




P: 1.800.830.0210  
F: 1.800.310.4874

**VERSARE**  
www.versare.com

3236 California St. NE  
Minneapolis, MN 55418


4

Place panels flat on the ground and attach plate loosely to end member panel.




5

Attach end member and plates to the main panels.



6

Stand up the partition and screw hinges onto wall.




P: 1.800.830.0210  
F: 1.800.310.4874

**VERSARE**  
www.versare.com

3236 California St. NE  
Minneapolis, MN 55418

7

Unbuckle straps.



All complete!  
We hope you enjoy your new  
Operable Wall!

If you have any questions on your Operable Wall, please contact us at  
1.800.830.0210 or  
customerservice@versare.com



P: 1.800.830.0210  
F: 1.800.310.4874

**VERSARE**  
www.versare.com

3236 California St. NE  
Minneapolis, MN 55418